

## Sony Reader: PRST1BC

### Setting up your new Sony Reader

#### Introduction

This document talks you through how set up and use your Sony Reader in New Zealand in conjunction with the Whitcoulls NZ eBook store.



#### Step 1 - Setting up your Sony Reader

When you first start up your Reader, select your preferred language then select **Australia** as your Country/Region. For local time zone, select **Auckland, New Zealand** and lastly, set the current time and date.




#### Step 2 - Connecting to your Computer

Make sure your PC or Mac is connected to the **internet**. Now connect your Reader using the supplied **USB** cable. To avoid potential problems, connect the Reader directly to a USB port and avoid using a USB Hub. Then select **Data Transfer Mode** on your Reader screen.



#### Step 3 - Installing Sony Reader Software

Navigate to the **Settings drive** (in **My Computer** for PC or on the **Desktop** for Mac) and start the installation for your PC or Mac. The installer will download files from the internet. When prompted, select **United States** as your region. Your Reader will then be detected and when prompted to **Authorize** it, select **Yes**. (If you already have the Reader software installed on your computer, connecting a new Sony Reader will still bring up the device authorization prompt).



Once the software is installed and launched, change your region to **Australia**. You do this in the **Edit/Preferences** menu at the top of your PC screen or in the **Reader for Mac/Preferences** menu on your Mac.

If Reader software automatically prompts you to update your device, agree and **update**. If not, click the **Help** tab and select **Check for Updates** manually. It's always best to have the latest software on your Reader.

## Sony Reader: PRST1BC

### Setting up your new Sony Reader



#### Step 4 - Purchasing eBooks

Under the **Store** tab of the Reader software, you will see a link to the **Whitcoulls Store**. Follow it or enter this address into your browser, <http://www.whitcoulls.co.nz/ebooks/ebooks/45/>

Create a Whitcoulls account or sign in to an existing one and purchase an eBook.


Once you've completed the transaction, go to your **eLibrary** on the Whitcoulls site where your purchase should be displayed in **My Reading List**.



#### Step 5 - Installing Adobe Digital Editions (ADE) Software

Before downloading your purchase to your computer, you need to install **ADE**. There's a link to the Adobe site in the text of the Whitcoulls **My eLibrary** page, or you can follow this link, <http://www.adobe.com/products/digitaleditions/>

Create a free **Adobe** account, then install and launch the ADE software. You need to authorise your computer in order to download copy-protected eBooks, so under the **Library** tab of ADE, select **Authorize Computer**.



#### Step 6 - Getting your purchases onto your Reader

Go back to **My eLibrary** on the Whitcoulls site and click on the text to the right of your purchased book that says **Download file (Adobe Digital Edition users)**.

Your browser may prompt you to **Open** or **Save** a **.acsm** file. Select **Open** and the purchased eBook will be automatically added to your **Reader Library** on your computer. Now all you need to do is Sync your Reader to the computer and you are good to go.



#### Note on ADE

Once this step is complete, you should not have to use ADE again as all your Reader content will be organised by the Reader for PC/MAC software on your computer.